Table of Contents

Chapter 1: Outline

1.1 About this Operation Manual 1-2
1.2 Features 1-3
1.3 Safety Precautions 1-4
1.4 Safety Labels 1-5

Chapter 2: Specifications

2.1 System Specifications 2-2
2.2 SAN Unit Specifications 2-3
2.2.1 Duty Cycle Calculation 2-3
2.2.2 SAN Unit Dimensions 2-4
2.3 Press Tool 2-6
2.3.1 Part Number Breakdown 2-6
2.3.2 Tool Specifications 2-7
2.3.3 Tool Dimensions 2-8
2.4 Functions 2-9

Chapter 3: System Description

3.1 System Block Diagram 3-2
3.2 DSP1500 Front Panel (SAN Unit) 3-3
3.2.1 DSP1500 Front Panel, Switches and Connectors 3-3
3.2.2 DSP1500 Front Panel Condition Display LED 3-4
3.2.3 DSP1500 Detachable Keypad Buttons 3-5
3.2.4 DSP1500 Detachable Keypad Condition Display 3-6
3.3 Press Tool 3-7
3.4 Connection Diagram 3-8

Chapter 4: System Setup and Wiring

4.1 Design and Build Procedures 4-2
4.2 SAN Unit Design and Mounting Dimensions 4-3
4.3 Calculating Circuit Protection 4-5
4.4 Input Power Supply Connection 4-6
4.5 Motor Power-Resolver Connections 4-7
4.6 Pre-Amplifier Connection 4-8
4.7 External Control Connection 4-9
4.7.1 PLC Interface (I/O) Signal Chart 4-9
4.7.2 Input & Output Recommended Connection Circuit 4-11
4.7.3 Input & Output Signal Explanation 4-12
4.7.4 Synchronized Press Operation 4-17
4.7.5 Operation Timing Chart 4-18
4.8 SW1 - SAN Unit Number Setting 4-19
4.9 MON. Signal (External Monitor Signal) 4-20
4.10 RS-485 Interface Signal 4-21

Table of Contents

4.11 Firmware Flash Connector..... 4-22
4.12 Cable Installation Guidelines..... 4-23
4.12.1 Considerations for Cable Trolleys 4-24
4.12.2 Considerations for Flexible Cable Track 4-24
4.12.3 Considerations for Cable Trays & Ladders 4-24
4.13 Tool Connections 4-25
4.14 Brake Option 4-26

Chapter 5: Powering Up and Initial Checks

5.1 Before Powering On 5-2
5.2 Initial Data Setting 5-4

Chapter 6: System Operation

6.1 Display and Programming Unit..... 6-2
6.1.1 DP2S and DP4S Serial Connection..... 6-3
6.1.2 RS232 Output Data..... 6-4
6.2 Function of Display and Operating Panel..... 6-6
6.3 RUN Status Mode Operating Instruction 6-7
6.3.1 Display 6-7
6.3.2 Mode Change 6-8
6.3.3 RUN Status Key Operation 6-9
6.3.4 Real Time Display Mode..... 6-10
6.3.5 Operation Result Display Mode..... 6-11
6.3.6 Set Value Display Mode..... 6-12
6.3.7 Operating Condition Display..... 6-14
6.3.8 Status Display Mode..... 6-15
6.4 BYPASS（Spindle Off）Mode Operating Instruction 6-16
6.4.1 Download Mode and Setup Mode Selection 6-16
6.4.2 Data Edit Mode 6-17
6.4.3 Parameter Copying..... 6-18
6.4.4 Data Number Conversion Table 6-19
6.4.5 Data Number Definitions..... 6-21
6.4.5.1 System Parameter (No. 00)..... 6-21
6.4.5.2 Work Parameters (No. 01~32)..... 6-25
Operation Methods..... 6-26
Operation Steps..... 6-35
Operation Finish Modes..... 6-37
Step Press..... 6-45
Considerations for Return Parameters..... 6-45
6.5 External LVDT Sensor..... 6-46

Table of Contents

Chapter 7: Maintenance & Inspection

7.1 Inspection Items…….. …….. 7-2
7.1.1 Press Tool …… 7-2
7.1.2 Press Fixture…… 7-2
7.1.3 Homerun Cables…….. 7-2
7.1.4 SAN Unit……..7-3
7.1.5 Air Handling Unit…….. 7-3
7.2 Basic Operational Tests..…….. 7-4
7.2.1 Load Cell…… 7-4
7.2.2 Resolver…… 7-4
7.2.3 Motor…… 7-5
7.2.3.1 Motor Replacement Procedure…….. 7-6
7.2.3.2 Explanation of Home Position Search..... 7-7
7.2.3.3 Motor Tuning..... 7-9

Chapter 8: Troubleshooting

8.1 Abnormal Display …….. 8-2
8.2 Load Cell Errors ……..…… …… 8-3
8.3 Offset Load Errors …… 8-5
8.4 Tool EEPROM Errors …… 8-6
8.5 System Memory Errors …….. 8-7
8.6 Servo Amplifier Response Errors …… 8-8
8.7 Servo Type Errors …… 8-9
8.8 Internal Errors …… 8-10
8.9 Servo Amplifier Errors …….. 8-11
8.10 Parameter Errors …… 8-13
8.11 Q & A...…… 8-15

Table of Contents

Appendix A: Reference Drawings

Power Wiring Reference - AC..... A-2
PLC I/O Wiring Reference – Allen Bradley (SLC)..... A-3
PLC I/O Wiring Reference – Omron..... A-4
PLC I/O Wiring Reference – Mitsubishi..... A-5
PLC I/O Wiring Reference – GE 90-30..... A-6
PLC I/O Wiring Reference – Modicon 984.....A-7
SAN Unit Connection Reference..... ..... A-8
Standard Transformers..... ..... A-9
Homerun Cable (SAN3-24S/40S) – Motor/Resolver..... A-10
Homerun Cable (SAN3-120S with RM4 Motor) – Motor/Resolver..... A-11
Homerun Cable (SAN3-120S with RM5 Motor) – Motor..... A-12
Homerun Cable (SAN3-120S with RM5 Motor) – Resolver..... A-13
Homerun Cable (SAN3-24S/40S/120S) – Load Cell (Pre-Amplifier).....A-14
Extension Cable (SAN3-24S/40S/120S with RM4 Motor) – Motor/Resolver..... A-15
Extension Cable (SAN3-120S with RM5 Motor) – Resolver..... A-15
Extension Cable (SAN3-120S with RM5 Motor) – Motor..... A-16
Extension Cable (SAN3-24S/40S/120S) – Load Cell (Pre-Amplifier)..... A-17
SAN3-24S/40S Unit Power Cable..... A-18
SAN3-120S Unit Power Cable..... A-19
I/O Connection Cable..... A-20
I/O Proximity Switch Breakout Adapter..... A-21
Homerun Proximity Switch Cable..... A-22
Tool / Extension Proximity Switch Cable..... A-23
Homerun Brake Cable..... A-24
Extension Brake Cable..... A-25
External Brake Unit & Cable..... A-26
RS-485 “Jumper” Cable..... A-27
RS-485 to RS-232 PC Converter Cable.....A-28